

**Attentions should be run before starting the engine**

**1) Open the pipe from REVERSE GEAR;**



**2) Open the bolt from REAR BRIDGE;**



**3) Open the pipe from ENGINE;**

